



FE120275 MVS LED Control Board

(Jumper JP1 Setup - pump stop/go or continuous run)



Jumper OFF
(jumper on 1 pin or removed)
Pump stop/go

For these 120 volts machines:
MVS 41X
MVS 45X series
MVS 52X - 120 volts



Jumper ON
(jumper on both pins)
Pump run continuously

For these machines:
MVS 48 series
MVS 50X
MVS 52X - 208 volts
MVS 52X-DV
MVS 65X