

MVS VacSmart "VacValve Disable"

1. Follow next instructions on the display to turn off the pump continuous run feature.



2. At HOME screen touch right arrow to scroll to SETTINGS.

3. Touch SETTINGS and locate USERS.

4. Touch USERS to go into USERS passcode creation section.



7. Enter 2 0 0 0 0 0 0 to deactivate the pump continuous running feature.

6. Press and hold number 5 until 8 small circles appear on the screen.

5. Touch ON to activate the passcode keypad.



8. VacValve Disabled will flash for 2 seconds to confirm and disappear.



9. Enter 0 0 0 to access the HOME page



10. Repeat step 2 to 5 and turn OFF the user passcode activation.

11. At HOME screen, touch RED power button and confirm shutdown of machine. When screen goes black, turn off main power switch, wait 1 minute, turn on the main power switch.

12. At HOME screen, touch right arrow to locate FREESTYLE.

13. In FREESTYLE close the lid to start the cycle. Verify machine vacuums, pump stops, seals the bag, air releases into chamber and lid opens.