

VacSmart™ by Minipack Chamber Vacuum Sealer Cleaning & Sanitizing Procedure



Prepare cleaning and sanitation solution.



Remove clear tray to wash area, clean and sanitize. Allow to air-dry.



Using cleaning solution, clean lid, chamber, body, and under machine. Allow to air-dry.



With cleaning solution, wipe down seal bars. Allow to air-dry.



Using sanitation solution, clean lid, chamber, body, and under machine. Allow to air-dry.



With sanitation solution, wipe down seal bars. Allow to air-dry.



Identify the correct orientation of the seal bars and re-install.