

# How to change oil in MX 3-4-5

MX3 drain/fill plugs are on left side of machine and MX4-5 drain/fill plugs are on the right side of the machine.

Scan QR code for video instruction. NOTE - Add new oil to half of sight glass.



## MX Unique Oil Cleansing Process

Each month the MX will prompt you to start the oil cleansing process, no matter how new or old. The oil cleansing process takes up to 4 minutes and evaporates moisture collected within the pump. You may delay the oil cleansing process, but this procedure is mandatory to extend the life of the pump.

Begin by REMOVING FOOD from chamber, HOLD LID DOWN FIRMLY WHILE PRESSING START!

GREEN - Oil is Excellent, no contamination found.

YELLOW - Oil is slightly contaminated and may run another cycle.

ORANGE - Oil is very contaminated and oil should be changed.

RED - The MX pump stops running and you must change the oil.

